

Floor Mat Installation During PDS

Service Category General

Section Pre-Delivery Service

Market USA



Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION	
2010	4Runner, Avalon,		
	Camry, Camry HV,		
	Corolla, FJ Cruiser,		
	Highlander, Highlander		
	HV, Land Cruiser,		
	Matrix, Prius, RAV4,		
	Sequoia, Sienna,		
	Solara, Tacoma,		
	Tundra, Venza, Yaris		

Introduction

2010 model year Toyota vehicles are equipped with driver's side floor mat retaining clips to help ensure the floor mat stays in the correct position. In addition, some models may utilize retaining clips for passenger's side floor mats as well. Attach the driver's side and passenger's side (if applicable) floor mat to the vehicle carpet using the floor mat retaining clips during Pre-Delivery Service (PDS).

CAUTION

- ONLY use a floor mat that can be retained using the retaining clips. All OEM Toyota floor mats are specifically designed to fit correctly and be retained using the retaining clips.
- Make sure the driver's side floor mat is properly placed on the vehicle carpet and secured with the retaining clips. If the floor mat is NOT properly placed and secured, it could slip and interfere with the movement of the pedals during driving and may cause an accident.
- Verify the operation of the accelerator, brake, and clutch (if equipped) pedals and clearance to the mat.
- **<u>NEVER</u>** install more than one floor mat at a time in the driver's seating position.
- If applicable, any secondary set of floor mats (based upon customer preference, such as the all weather floor mats or other floor mats) MUST be placed in the trunk/cargo area with all the packaging material intact. Do NOT install the secondary mat on top of the primary floor mat already installed in the driver's seating position.

Floor Mat Installation During PDS

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

Installation Procedure

Attach the driver's side and passenger's side (if applicable) floor mat to the vehicle carpet using the clips. Secure the mat by inserting the retaining clips through the grommet holes.

Figure 1. Correct Installation



Figure 2. Incorrect Installation

