

Service Category	Vehicle Interior			
Section	Seat Belt	Market	USA	Toyota Supports

Applicability

YEAR(S)	MODEL(S)	ADDITIONAL INFORMATION	
2009	4Runner, Avalon,		
	Camry, Camry HV,		
	Corolla, FJ Cruiser,		
	Highlander, Highlander		
	HV, Land Cruiser,		
	Matrix, Prius, RAV4,		
	Sequoia, Sienna,		
	Tacoma, Tundra,		
	Venza, Yaris		

TSB REVISION NOTICE

- June 24, 2009 Rev1:
 - Applicability and Seat Belt Extender Application sections have been updated to include 2009 Venza.

Any previous printed versions of this service bulletin should be discarded.

Introduction

Toyota customers who find it necessary to increase the length of their seat belts may obtain Seat Belt Extenders at no cost through their local Toyota dealer.

- The extender is available in 6-inch, 9-inch, 12-inch, 15-inch, and 18-inch lengths.
- The extender is available only in black.
- Owners are informed of the Seat Belt Extender availability through the Owner's Manual included in each vehicle.

The customer (individual requiring the extender) must visit a Toyota dealership to have the required measurements made and to complete the Seat Belt Extender Worksheet. The worksheet will allow the proper fitting and selection of a Seat Belt Extender for the customer. The dealership personnel should then determine the applicable part number and place an order through Dealer Daily.

Introduction (Continued)

The dealership service department should complete the affixed Seat Belt Extender Customer Information Label on the part and review the "Owner Instructions" (page 4) with the customer. The dealership should give a copy of the completed worksheet and Owner Instructions to the customer and keep the originals in the customer's file. To assure utmost owner satisfaction, it is recommended that a dealership designate one person to coordinate all activities related to the Seat Belt Extender issue. It is recommended that **dealerships do NOT stock** Seat Belt Extenders due to the need for proper fitting to individual customers.

This bulletin contains the following information:

- Procedure and Sample Label
- Application Charts
- Part Number Information
- Owner Instructions
- Seat Belt Extender Worksheet

Warranty Information

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-

Repair Procedure

- 1. Customer requests a Seat Belt Extender from dealer.
- 2. Dealer verifies the need for a Seat Belt Extender and obtains a current copy of this TSB and copies the worksheet.
- 3. Dealer measures the customer and completes the worksheet. Dealer determines the correct part number and places an order for the part through Dealer Daily.
- 4. Dealer receives Seat Belt Extender and calls the customer to check the fit of the part.
- 5. If the Seat Belt Extender fit is good, dealership personnel completes the Customer Information Label on the part, explains usage of the part, and gives the customer a copy of the completed worksheet.
- 6. Dealer places copy of the completed worksheet in the customer's records.

Toyota Seat Belt Extender

Repair Procedure (Continued)

Figure 1.




Figure 2. Sample Seat Belt Extender Customer Information Label

CAUTION

THIS SEAT BELT EXTENDER IS TO BE USED ONLY BY: _____

ON VEHICLE:

VIN: _____

SEATING POSITION:

USE BY OTHERS, OR IN ANOTHER SEATING POSITION, OR IN ANOTHER VEHICLE COULD REDUCE SEAT BELT RESTRAINT IN AN ACCIDENT AND RESULT IN PERSONAL INJURY.

Front Seat Belt Extender Applications

FROI	NT SEAT — EXTENDER APPLIC	CATION
MODEL	ТҮРЕ	2009
Yaris		K-6
Rav4		R-8
Corolla (TAKAOKA / KANTO Production)		R-8
Corolla (TMMC Production)		R-8
Corolla (NUMMI Production)		R-8
Matrix		R-8
Prius		R-8
Camry		R-8
Camry HV		R-8
Avalon	All Models	K-6
Sienna		R-8
Tacoma		R-7*1, R-8*2
4Runner		K-7
Land Cruiser		R-8
Highlander		R-8
Highlander HV		R-8
FJ Cruiser		K-7
Sequoia		R-8
Tundra		R-8
Venza		R-8

*1 : Bench Type

*2 : Separate Type

Rear Seat Belt Extender Applications

REA	R SEAT — EXTENDER APPLIC	ATION
MODEL	ТҮРЕ	2009
Yaris		R-8
Rav4		R-8
Corolla (TAKAOKA / KANTO Production)		K-5
Corolla (TMMC Production)		T-1
Corolla (NUMMI Production)		T-1
Matrix		T-1
Prius		R-8
Camry		R-8
Camry HV		R-8
AVALON		R-8
Sienna		R-8, Q-6*1
Tacoma (Extra Cab)	All Models	T-1
Tacoma (Double Cab)		T-1
4Runner		K-7* ² , R-8* ³ ,
Land Cruiser		K-7, K-8*4
Highlander		R-8
Highlander HV		R-8
FJ Cruiser		R-8
Sequoia (Rear No. 1 Seat)		R-8
Sequoia (Rear No. 2 Seat)		R-8
Tundra (Access Cab)		R-8
Tundra (Double Cab)]	R-8
Venza		K-5* ⁵


*1: for the rear No. 1 RH seat of 7 passenger's models and the center seats of the rear No. 1 and No. 2 seats

- *2: for the rear No. 1 seat
- *3: for the rear No. 2 seats
- *4: for the center seats of the rear No. 1 and No. 2 seats
- *5: a seat belt extender must not be used for the center rear seat belt.

Toyota Seat Belt Extender

Rear Seat Belt Extender Applications (Continued)

Figure 3. Example of Sienna



Part Number Information

		PART NUMBER	PREFIX: 73399		
SERIES	6 INCH	9 INCH	12 INCH	15 INCH	18 INCH
R-7	-48010	-48020	48030	-48040	-48050
R-8	-50060	-50070	-50080	-50090	-50100
K-5	-35010	-35020	-35030	-35040	-35050
K-6	-35060	-35070	-35080	-35090	-35100
K-7	-60010	-60020	-60030	-60040	-60050
Q-6	-AE061	-AE071	-AE081	-AE091	-AE101
T-1	-01110	-01120	-01130	-01140	-01150

Toyota Seat Belt Extender

Owners Instructions

Failure to follow the recommendations indicated below could result in reduced effectiveness of the seat belt restraint system in case of vehicle collision, causing personal injury.

If your seat belt cannot be fastened securely because it is not long enough, a personalized Seat Belt Extender is available from your dealer free of charge.

Please visit your local dealer so that the dealer can order the proper required length extender. Bring the heaviest coat you expect to wear for proper measurement and selection of length. Additional ordering information is available at your dealer.

When the Seat Belt Extender is provided for rear seat positions (with automatic locking retractor), make sure the retractor is locked when in use.


To connect the extender to the seat belt, insert the tab into the seat belt buckle so that the buckle-release buttons of the extender and the seat belt are both facing outward as shown.

You will hear a click when the tab locks into the buckle. When not in use, remove the extender and store in the vehicle for future use.

CAUTION

On vehicles equipped with SRS – Occupant Classification System (OCS)*, it is critical that the extender tab be buckled into the buckle AFTER the occupant sits down in the seat.

Leaving extender installed in the buckle before sitting down will cause the OCS to be in the "airbag off" or disarmed state.



1	Seat Belt
2	Extender

*OCS will enable or disable the passenger front and side airbags based on passenger weight and seat belt latch position classifying the passenger as a child or adult.

CAUTION

When using the Seat Belt Extender, observe the following. Failure to follow these instructions could result in reduced effectiveness of the seat belt restraint system in case of vehicle accident, increasing the chance of personal injury.

- NEVER use the Seat Belt Extender if you can COMFORTABLY fasten the seat belt without it.
- The Seat Belt Extender must never be used with any child safety seats.
- Remember that the extender provided for you may not be safe when used on a different vehicle, or for another person or at a different seating position than the one originally intended for.

Toyota Seat Belt Extender

CAUTION: • To minimize the chan 1 By the person for 2 In the seat positive • The Seat Belt Exten • When the Seat Belt make sure the retranged	or whom it was tion for which it ider must never Extender is pro	provided. was provide be used wit vided for rea	ed. h any child safety ar seat positions (seats.		
DEALER DEALER CODE DEALER NAM		BELT EXTE	NDER APPLICA	TION	APPL	ICANT
ADDRESS			ADDRESS			
CITY & STATE		ZIP	CITY & STATE		ZIP	PHONE
EMPLOYEE NAME	MODEL YEAR	BODY TYPE	SEATING POSITION	VEHICLE IDENTIFIC	CATION NUMBI	ER
 6. Seat Belt Extender leng Check Number). NOTE: If extender length exc CAUTION: On vehicles equipped tab be buckled into th Leaving extender inst or disarmed state. 	ceeds Check Numb I with SRS - Occ ie buckle AFTEF	oer, an extende cupant Class R the occupa	r <u>cannot</u> be provided sification System int sits down in th tting down will ca	d to the custome (OCS), it is cr ne seat.	er. ritical that	
NAVEL TO BUCKLE	SEAT	Navel	Dimension B: LATCH TO BUC Buckle		A	- Latch
DIMENSION A:		ENSION B:		CHECK NUM	BER:	
			DER AUTHORIZ	ATION		